




Dually pump retrofit kit

For use with retrofit kit P/N PLU09970400 and with pump P/N PUM22000558




Discharge return L2

Suction L2

Heater return L1

Suction L1



Discharge return L2

Heater return L1


Suction L1

Dually pump - pressure switch style equipment

The heater is located on top of control box.
Cut all four lines plumbed to the pump.

Dually pump - pressure switch style equipment

Plumbing configuration for heater is located on top of control box.



Suction L2

Discharge return L2

Heater return L1

Dually pump - pressure switch style equipment

Heater is located on top of control box.



Dually Pump Retrofit Kit part # PLU09970400


- PLU21800281 (quantity 1)
- PLU21800291 (quantity 1)
- PLU21800371 (quantity 1)
- HEA147001020 (quantity 2)
- PLU21002230 (quantity 2)
- PLU21000370 (quantity 1)
- PLU21500310 (quantity 2.5 ft.)



Dually pump retrofit kit

For use with retrofit kit P/N PLU09970400
and with pump P/N PUM22000558

Cut all lines plumbed to pump leaving enough length to re-plumb the kit.



Heater return L1

Suction L1

Dually Pump – M7 control equipment

Heater is located on the bottom of the control box.
Cut all four lines plumbed to the pump.




Heater return L1

Suction L1

Dually Pump – M7 control equipment

Plumbing configuration for heater located on bottom of control box.



Heater return L1

Suction L2

Discharge return L2

Dually Pump – M7 control equipment

Plumbing configuration for the heater is located on bottom of control box.



Dually Pump Retrofit Kit part # PLU09970400

- PLU21800281 (quantity 1)
- PLU21800291 (quantity 1)
- PLU21800371 (quantity 1)
- HEA147001020 (quantity 2)
- PLU21002230 (quantity 2)
- PLU21000370 (quantity 1)
- PLU21500310 (quantity 2.5 ft.)